

ATLANTIS HYPERSCALE A

SPECIFICATIONS: CX-12-HP / CX-24-HP



SERVER SPECIFICATIONS	CX-12-HP			CX-24-HP	
Server Compute (per node)	HP ProLiant DL360 Gen91 w/ Two Intel E5-2680 v3 12-Cores Processors				
Hypervisor	VMware vSphere 5.5 or Citrix XenServer 6.5				
Memory (per node)	256GB-768GB		384GB-768GB		
Networking	2x 10GbE & 2 x 1GbE				
STORAGE					
All-Flash Effective Capacity (TB) ² (Per 4-Node Appliance)	12 TB			24 TB	
Local Flash Storage (per node)	3x 400GB SSD, 32GB Fla	ash Media 3x 800GB		SSD, 32GB Flash Media	
Storage Resiliency Policy	HA Enabled with Single Host Failure Protection ³				
GENERAL PURPOSE SERVER VIRTUAL MACHINE DENSITY (2 vCPU, 4GB RAM, 50GB)					
Server VMs (Per 4-Node Appliance)	170		365		
VIRTUAL DESKTOP DENSITY (CX-12 / CX-24)					
Maximum Number of Virtual Desktops (Per 4-Node Appliance)	Task Worker (20GB, 1vCPU, 1.5GB RAM LoginVSI Task Worker)	Knowledge Worker (50GB, 2vCPU, 2GB RAM LoginVSI Knowledge Worker)		Power User (100GB, 2vCPU, 4GB RAM LoginVSI Storage Workload)	
Stateless VDI	800 / 800	600 / 600		300 / 350	
Persistent VDI	450 / 800	350 / 600		175 / 350	

 $^{{\}tt 1} \ \, {\tt For \ detailed \ information, \ please \ read \ the \ HP \ ProLiant \ DL360 \ Gen 9 \ Server \ data sheet.}$

U.S. Headquarters

2525 E. Charleston Road, Suite 100 Mountain View, CA 94043

PHONE: 650.917.9471

EMAIL: sales@atlantiscomputing.com

TWITTER: @AtlantisSDS

European Headquarters

Birchin Court, 20 Birchin Lane London. EC3V 9DU

London, ECSV 9DO

PHONE: +44 2034052851

TWITTER: @AtlantisSDS

ting, Atlantis HyperScale, Atlantis USX, Atlantis HyperDup are



² All-Flash Effective Capacity is the capacity available after a 70% data reduction and resiliency of 1 out of 4 nodes failing. See the Hyperscale Storage Guarantee at www.atlantiscomputing.com/hyperscale for more details.

³ High Availability enabled with a single host failure of 1 means that any one of the 4 nodes can fail or lose power and the storage of the hyper-converged system will continue to operate. In a failure scenario with a single failed node, the number of virtual servers or desktops may be limited depending on the resources available. The hypervisor's High Availability can be configured to restart VMs of a failed node on the remaining three nodes.